

Maintenance Overview

While Re-Tire Basics, Medley & Kaleidoscope are tough and flexible products, Re-Tire requires a floor finish to protect the surface of the flooring and ease maintenance. After the finish is applied initially, it is the responsibility of the end user to maintain the finish over time to ensure long-term protection and ease of maintenance. Re-Tire requires daily and routine maintenance with cleaning equipment to maintain the desired appearance. The frequency of daily and routine maintenance will depend upon the amount and type of traffic in the area.

Floor protection is a critical part of any long-term maintenance program for resilient flooring. Ensure that all chair casters and glides are manufactured from materials that are intended for resilient flooring to avoid indentation and flooring or finish

damage. Ensure that all furniture feet have proper floor protection devices installed to avoid premature wear, scratches and other damage. **See Section 10 for details on floor protection.**

When conducting daily maintenance, always use untreated, new or thoroughly cleaned mops and pads. Do not use hydrocarbons (Kerosene, Gasoline, Naphtha, etc.) or solvents to clean flooring. As with any maintenance program, be sure to use proper PPE (Personal Protective Equipment) per the cleaning product SDS and ensure all maintenance procedures are conducted per the cleaning products instructions. The use of Caution Tape and / or Wet Floor Signs are recommended to prevent slips and falls.

Additional Information

Approved Cleaners

Capri Neutral Cleaner
Hilway Direct Plus (as a Cleaner/Maintainer)

Approved Finish Removers

AllSafe Stripper

Approved Finishes

Hilway Direct Plus
Loba InvisibleProtect

Technical Support

Additional technical resources and documents are available online at capricollections.com. For additional technical support, send an e-mail to support@capricollections.com

1. PRE-MAINTENANCE

- Prior to moving furniture or heavy equipment, sweep the floor and cover with an appropriate protective product, such as Masonite, Ram Board or equivalent, to prevent scuffing and scratching that may not come out during initial maintenance.
- **Do not** use vacuums that have a beater bar or electric brooms with hard plastic bottoms or no padding, as this may cause discoloration, scratching and loss of sheen.
- **Do not** use detergents, highly alkaline, acidic or abrasive cleaners or "mop and shine" type products, as they may dull or damage the finish of the flooring material.
- **Do not** use sweeping compounds or cleaning agents that contain hydrocarbons or solvents.
- **Do not** scrub, buff or mop the area per the adhesives traffic limits (48-72 hours) to allow proper curing of the adhesive.
- **Do not** over-saturate the area when cleaning.
- **Do not** allow the cleaning solution or topical moisture to work its way beneath the flooring material, as this can result in an adhesive failure.

2. INITIAL MAINTENANCE

Ensure that adhesive has cured for recommended period of time

prior to conducting initial maintenance. Remove any protective coverings prior to cleaning. Sweep or dust mop and vacuum flooring to remove any dirt, dust or debris.

Mix 6 - 7 oz. of Capri Neutral Cleaner per gallon of warm and clean potable water (1:20) and use a clean mop to apply cleaning solution to area. Let solution stand for 5-10 minutes.

Using a low-speed (180 – 360 RPM) floor buffer, swing single disc scrubber or auto-scrubber, scrub the floor while wet using a 22 gauge soft bristled scrubbing brush or a 3M 5100 Red Cleaning Pad. If flooring is heavily soiled, an additional cleaning may be required.

Use an auto-scrubber, wet vacuum or clean mop to remove any and all excess cleaning solution. Rinse area with clean, cool water and ensure that all cleaning residue has been removed (this may require additional rinsing). Allow area to dry completely before allowing foot traffic.

3. INITIAL FINISH APPLICATION

Ensure that initial maintenance has been conducted prior to applying the Hilway Direct Plus. Flooring area must be free of dust, dirt, debris, adhesive or cleaning residues and any potential contaminants. **Do not** dilute finish or apply to surfaces below 50° F.

Shake floor finish container vigorously prior to application. Use a microfiber mop to apply finish in a thin, even film per the installation instructions in 2-3 coats, applying each coat in a

perpendicular direction to the previous coat. Allow each coat to dry completely before applying additional coats. Avoid direct forced air, drafts and direct sunlight during application and curing.

Once the second coat is dry, evaluate the floor to determine if an additional coat is necessary. If heavy use is expected, a third coat is recommended. Allow the final coat of finish to dry overnight before allowing normal traffic. Wait 24 hours before allowing heavy traffic and rolling loads.

To prolong the life of the finish, the finish should receive routine maintenance via a cleaner/maintainer or spray buffing. Please see section 5 and 6 for more information.

For additional information regarding the finish and finish application, please see the Hilway Direct Plus Technical Data Sheet.

4. DAILY MAINTENANCE

Ensure that initial maintenance and finish application has been conducted prior to conducting daily maintenance. Sweep or dust mop and vacuum flooring to remove any dirt, dust or debris. Do not use vacuums that have a beater bar or electric brooms with hard plastic bottoms or no padding, as this may cause discoloration, scratching and loss of sheen. When using a mop, use a two bucket system for cleaning - one bucket with cleaning solutions and another bucket with clean, potable water for rinsing.

If using a mop, mix 0.5-1 ounce or 20 mL (1:200) of Capri Neutral Cleaner per gallon of clean, potable water. Use a clean mop to clean spills, build-up, dirty areas or overall cleaning. Allow floor to dry completely before allowing foot traffic.

If using an auto-scrubbing machine, mix 0.25-0.5 or 10 mL (1:400) of Capri Neutral Cleaner per gallon of warm and clean potable water. Buff or scrub floor while wet using a 22 gauge soft bristled scrubbing brush or a 3M 4100 White Super Polish Pad.

Use an auto-scrubber, wet vacuum or clean mop to remove any and all excess cleaning solution. Rinse area with clean, cool water and allow floor to dry entirely. Ensure flooring area is clean and that all cleaning residue has been removed (this may require additional rinsing).

5. ROUTINE MAINTENANCE - CLEANER/MAINTAINER

In addition to a floor finish, the Hilway Direct Plus can also be used as a cleaner/maintainer in order to prolong the life of the finish or repair marred areas. Ensure that daily maintenance has been performed, if necessary. Sweep or dust mop and vacuum flooring to remove any dirt, dust or debris. When using the cleaner/maintainer, use a two bucket system for application - one bucket with the cleaner/maintainer solution and another bucket with clean, potable water for rinsing.

Mix 1 ounce or 30 mL (1:128) of Hilway Direct Plus per gallon of warm, clean potable water. Use a clean microfiber mop or an auto-scrubbing machine with 22 gauge soft bristled scrubbing brushes or 3M 4100 White Super Polish Pads to clean the entire

floor.

Use an auto-scrubber, wet vacuum or clean, dry mop to remove any and all excess cleaning solution. Do not rinse the flooring after cleaning. Allow area to dry completely before allowing foot traffic.

6. ROUTINE MAINTENANCE - SPRAY-BUFFING

In addition to a floor finish, the Hilway Direct Plus can also be used to spray-buff flooring in order to restore the finish periodically. Ensure that daily maintenance has been performed, if necessary. Sweep or dust mop and vacuum flooring to remove any dirt, dust or debris.

Using an unused or thoroughly cleaned spray bottle, mix the finish with warm, clean potable water at a ratio of 1:5 (finish:water). Spray the diluted finish onto the floor and buff immediately using a low-speed floor buffer or swing single disc scrubber (180 – 360 RPM) and a 3M 4100 White Super Polish Pad.

Do not rinse the flooring after buffing. Allow area to dry completely before allowing foot traffic.

7. FINISH REMOVAL & REAPPLICATION

If Hilway Direct Plus has been applied to the flooring material, the finish may need to be regularly removed and reapplied, depending on traffic. The timing of removal will depend on the age and condition of the finish, as well as the frequency of daily/routine maintenance and spray-buffing.

Sweep or dust mop and vacuum flooring to remove any dirt, dust or debris. Using a new or thoroughly cleaned mop, apply Allsafe Stripper undiluted to the flooring material and allow to remain on the surface for 15 - 20 minutes. Do not allow finish remover to dry onto the floor.

Using a low-speed floor buffer or swing single disc scrubber (180 – 360 RPM), scrub floor while wet using a 22 gauge soft bristled scrubbing brush or a 3M 5100 Red Cleaning Pad.

Use an auto-scrubber, wet vacuum or clean mop to remove any and all excess cleaning solution. Rinse area with clean, cool water and allow floor to dry entirely.

Reapply the desired floor finish per the installation instructions in 2 - 3 coats. Allow each coat to dry completely before applying additional coats.

For additional information regarding the finish and finish application, please see the Hilway Direct Plus Technical Data Sheet.

8. INITIAL FINISH APPLICATION - INVISIBLEPROTECT

In some situations, a urethane finish may be preferred. Urethane finishes take a great deal of care to apply and cure correctly. Ensure that initial maintenance has been conducted prior to applying floor finish. Flooring area must be free of dust, dirt, debris, adhesive or cleaning residues and any potential contaminants. Ensure that HVAC is operation - installation area and flooring material must be between 60° and 75° F during application and curing. Avoid direct forced air, drafts and direct sunlight during application and curing. **Do not** dilute finish or

apply to surfaces below 50° F.

Loba Supra AT is a two-component product. Shake both components of Supra AT vigorously prior to mixing. Add Part B directly to Part A, reseal and shake vigorously to mix both components together. Once mixed, pour the finish into a clean paint tray for application.

If possible, application should start at the primary light source and work away from it, in order to make finish imperfections (such as puddles, skips and voids) easier to identify and correct. Use 120g microfiber roller or equivalent to apply the finish in a thin, even coat. Apply material perpendicular to, then towards light source. Avoid puddles, pooling, skips and voids - correct imperfections as quickly as possible during application. Prevent all foot traffic, dust and debris from entering the area and allow material to cure for a minimum of 2 hours.

Once the first coat has cured initially, apply the second coat of Loba InvisibleProtect as above **within 24 hours**. Allow the finish to cure for 12 hours before allowing light foot traffic. Do not resume normal use for 24-48 hours. Finish will fully cure in 7 days - avoid objects which could scratch or damage the floor until the finish has fully cured. Do not use flooring cleaners or cover with area rugs for 10 days.

For additional information regarding the finish and finish application, please see the Loba InvisibleProtect Technical Data Sheet.

9. FINISH REMOVAL & REAPPLICATION - INVISIBLE PROTECT

If Loba InvisibleProtect has been applied to the flooring material, the finish may need to be abraded and re-coated, depending on wear and traffic. Sweep or dust mop and vacuum flooring to remove any dirt, dust or debris.

Using a low-speed floor buffer or swing single disc scrubber (180 – 360 RPM), abrade the floor with a 3M Maroon Surface Prep Pad or equivalent to remove the surface of the finish. For corners, edges and hard to reach areas, cut a 3M Maroon Surface Pre Pad to a suitable size and abrade by hand. Once complete, the floor should have a uniform dull appearance.

Vacuum the floor to remove all dust, dirt and debris. Clean the floor with a terry cloth, microfiber towel or a flat microfiber mop and clean, potable water. Allow floor to dry completely prior to proceeding.

Reapply the Supra AT per the installation instructions in 2 coats. Allow finish to cure for at least 12 hours before allowing light foot traffic.

For additional information regarding the finish and finish application, please see the Loba InvisibleProtect Technical Data Sheet.

10. FLOORING PROTECTION

Protect newly installed flooring with construction grade paper or protective boards, such as Masonite or Ram Board, to protect flooring from damage by other trades. Do not slide or drag pallets or heavy equipment across the new flooring. Limit usage and foot traffic according to the adhesive's requirements. When moving appliances or heavy furniture, protect flooring from scuffing and tearing using temporary floor protection.

All furniture casters or glides must be intended for resilient flooring and made of a soft material (such as a rubber or poly-based material). Casters and glides must have a flat contact point that is at least 1" sq. in. or 1.25 in. in diameter to limit indentation and flooring or finish damage. All rolling seating or furniture that does not meet these guidelines must have a resilient flooring chair pad installed over the finished floor to protect floor covering.

All fixed furniture legs or corners must have permanent felt or soft rubber floor protectors installed on all contact points to reduce indentation, wear, scratching and other flooring or finish damage. Floor protectors must have a flat contact point of at least 1 sq. in. or 1.25 in. diameter and must cover the entire bottom surface of the furniture leg.

Ensure all furniture castors and chair legs are clean and free of any and all dirt and debris. Routinely clean chair castors and furniture legs to ensure that dirt or debris has not built up or become embedded in castors or floor protectors. Replace chair castors and floor protectors at regular intervals, especially if they become damaged or heavily soiled.

Place walk-off mats at outside entrances. Prevent water and moisture from accumulating underneath walk-off mats. Ensure mats are manufactured with non-staining backs to prevent discoloration.

For more information regarding cleaner application, floor finish application or finish removal, please consult all associated product data sheet, SDS and warranty information.