

Background

In light of the unprecedented COVID-19 pandemic that is sweeping many countries around the world, many facilities have a renewed interest in surface disinfection, including floor coverings. While hospitals and healthcare facilities routinely follow infectious control and disinfection guidelines, this is likely uncharted territory for commercial and residential facilities.

This technical bulletin is intended to provide guidance on disinfecting procedures, including compatible disinfecting chemicals and proper dilution ratios based on relevant

chemical resistance testing. The provided information is publicly available and fact-based information from the Center for Disease Control and Prevention (CDC), the Center for Health Design (CHD), the Environmental Protection Agency (EPA) and the Facility Guidelines Institute (FGI). As such, this information is subject to continuous improvement and revision – the current guidelines and documents available from these organizations supersede any documents and guidelines referenced herein.

General Precautions

Any damage to floor covering or other property caused by improper, incompatible or incorrectly used cleaning chemicals, as well as resulting health issues, will not be covered under warranty. As with all chemicals, ensure that all hazardous information, including associated Safety Data Sheets (SDS), are read, understood and followed. Wear proper Personal Protective Equipment (PPE) when

handling chemicals and avoid exposure to skin or eyes and ingestion at all costs. Please review individual warranty documents carefully prior to use for more information regarding warranty coverages. This bulletin is subject to change - please visit capricollections.com or contact the Capri technical department for the most current version.

Understanding Common Terms

When discussing cleaning, the CDC Guideline for Disinfection and Sterilization in Healthcare Facilities provides the following definitions for some common terms:

- 1. **Cleaning:** Removal, usually with detergent and water, of adherent visible soil, blood, protein substances, microorganisms and other debris from the surfaces. Cleaning does not always kill microorganisms, but removing them limits exposure and reduces the risk of spreading infection.
- 2. Sanitizing: A process that reduces the number of bacterial contaminants to safe levels as judged by public health requirements. Sanitizing does not clean surfaces and should only be performed following cleaning.
- 3. Disinfecting: Chemical destruction of microorganisms, pathogenic or otherwise. Disinfection does not always clean surfaces or physically remove microorganisms but disinfecting after cleaning can further reduce the risk of spreading infection.

4. Sterilizing: A validated process used to render a product free of all forms of viable microorganisms. Sterilization is generally only required for objects that will come into direct contact with bodily fluids.

For the purposes of this technical bulletin, we will be primarily focusing on removing and destroying microorganisms through cleaning and disinfecting Capri floor covering products.

Cleaning Guidelines

Capri products do not sponsor organic growth, including the growth of microorganisms, and are inherently inconducive to the spread of infection. Furthermore, they are easy to clean with readily-available pH neutral floor cleaners, which will remove microorganisms, organic matter, surface stains, dirt accumulation and other foreign matter that may interfere with surface disinfection.

With this in mind, maintenance is a crucial first step in any disinfection process. All Capri products should be thoroughly cleaned following the associated Maintenance Guide, followed by a thorough rinsing with clean potable water, to remove as much foreign material from the surface of the flooring as possible. Doing so will greatly improve



Capri Collections

the efficacy of disinfection. For more detailed information on routine and daily maintenance for Capri products, please refer to the relevant maintenance instructions.

Disinfection Guidelines

Once flooring is cleaned, additional disinfecting techniques and procedures may be requested or required in order to ensure that spaces are safe, clean and free from infectious disease. The following is some general guidance for Healthcare, Commercial and Residential spaces that require disinfection.

The disinfection procedures in healthcare environments are typically regulated by four main sources:

- The CDC Guideline for Disinfection and Sterilization in Healthcare Facilities (2008), which references EPA's list of registered disinfection chemicals and disinfection instructions.
- 2. The FGI Guidelines for Design & Construction (2018), which provides separate guidelines for hospitals, outpatient facilities and residential healthcare facilities. Additionally, it includes design guidelines related to Infectious Control and the CHD SRA toolkit.
- **3.** The CHD Safety Risk Assessment (SRA) Toolkit (2020), which helps facilities identify latent risks related to infection in order to mitigate them.
- 4. CHD Design Strategies Environmental Surfaces & HAIs (2019), intended to help limit Healthcare-Associated Infections (HAIs) through proper environmental surface selection and cleaning processes. Includes specific guidance for flooring materials.

According to these guidelines, there are three levels of disinfection:

- 1. **High-Level:** Requires the use of strong disinfectants, such as glutaraldehyde and other chemical sterilant. These are intended for critical and semi-critical environmental surfaces, not floor covering.
- 2. Intermediate-Level: Requires the use of EPAregistered, tuberculocidal disinfectants. These are intended for semi-critical and noncritical environmental surfaces, especially that come into direct contact with skin.

3. Low-Level: Requires the use of EPA-registered disinfectants, but they do not need to be tuberculocidal. These are intended for non-critical environmental surfaces, like floor covering.

Since floor covering is considered a non-critical environmental surface within healthcare facilities, only an EPA-registered low-level disinfectant is required to disinfect Capri products. Healthcare facilities typically have EPA-registered disinfectants readily available through a pre-approved vendor. Many of these disinfectants are quaternary disinfectants that have a pH between 6 and 10.5 - these products are generally safe for use on Capri products. The following disinfectants are approved for use:

Approved Disinfectant Cleaners

- Diversey Virex II 256 Disinfectant
- Eco-Lab Multi-Purpose Disinfectant Cleaner
- Spartan HDQ Neutral
- Spartan Super HDQ
- XL North Vital Oxide

^^^^^

There are several other products that are EPA-registered disinfectants – in fact, new products are added to the EPA's registered list routinely. As such, if you intend to disinfect Capri products with a disinfectant that is not on this list, but is otherwise registered and approved, be sure to follow all of the disinfectant manufacturer's instructions regarding dilution, mixing and application. Be sure to test the disinfectant solution on an uninstalled piece of flooring material to confirm that the disinfectant will not discolor, damage or attack the surface of the flooring material. Be sure to check for loss of sheen or any other subtle changes in appearance as well.

In additional to commercially available disinfectant solutions, Capri products can also be disinfected with a solution of clean, cool potable water and up to 10% Hydrogen Peroxide or up to 10% Sodium Hypochlorite (bleach). Ensure areas that are treated with these chemicals are rinsed with clean, cool potable water following initial application in order to remove any remaining cleaning solution and residue.

Summary

In general, Capri products will not contribute to the spread of infectious diseases on their own - only poor cleaning and disinfecting practices will. As such, if the cleaning and





Technical Bulletin

disinfecting guidelines outlined in this technical bulletin and the supporting product maintenance guides are followed, Capri products will provide an easy to clean and disinfect floor covering. This will enable healthcare, commercial and residential facilities to adequately prevent the spread of microorganisms and infectious diseases.

For additional information, please consult the associated technical data sheets and care & maintenance documents. For additional assistance, please contact Capri technical services: 1.800.492.2613 - support@capricollections.com